

Алматы (7273)495-231	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Тверь (4822)63-31-35
Ангарск (3955)60-70-56	Ижевск (3412)26-03-58	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тольятти (8482)63-91-07
Архангельск (8182)63-90-72	Иркутск (395)279-98-46	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Астрахань (8512)99-46-04	Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)33-79-87
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Саранск (8342)22-96-24	Тюмень (3452)66-21-18
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Санкт-Петербург (812)309-46-40	Ульяновск (8422)24-23-59
Благовещенск (4162)22-76-07	Кемерово (3842)65-04-62	Ноябрьск (3496)41-32-12	Саратов (845)249-38-78	Улан-Удэ (3012)59-97-51
Брянск (4832)59-03-52	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Владивосток (423)249-28-31	Коломна (4966)23-41-49	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Владикавказ (8672)28-90-48	Кострома (4942)77-07-48	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Чебоксары (8352)28-53-07
Владимир (4922)49-43-18	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Челябинск (351)202-03-61
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Череповец (8202)49-02-64
Вологда (8172)26-41-59	Курск (4712)77-13-04	Петрозаводск (8142)55-98-37	Сургут (3462)77-98-35	Чита (3022)38-34-83
Воронеж (473)204-51-73	Курган (3522)50-90-47	Псков (8112)59-10-37	Сыктывкар (8212)25-95-17	Якутск (4112)23-90-97
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81		Тамбов (4752)50-40-97	Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132


Киргизия +996(312)96-26-47

www.ermo.nt-rt.ru | eor@nt-rt.ru

Технические характеристики на навесные пилы FS.1, FSV.2 компании **ЕРМО**

Single and double share ploughs

The product range that suits every tractor.



ERMO products meet any need, from "lighter" ploughing carried out with low-power tractors (45hp), to deep working or trenching activities (up to 500hp) for new vineyards and orchards.

- with hydraulic lateral movement for on-land or in-furrow works;
- with lateral movement with hydraulic slight for on-land or in-furrow and field finishing works. From model FS.1|90 it is possible to mount a rear-working element (called extra body). In order to simplify the root-cutting process during trenching activities, it is also possible to mount a coulter on every product of the ERMO single-share plough range.

Technical specifications

Single share

Double share

TYPE	N. OF BODIES	POWER (HP)	WORKING WIDTH (CM)	WORKING DEPTH (CM)	HEIGHT (CM)	WEIGHT (KG)	MOULDBOARD
FS.1 87	1	90 100	50 60	35 50		800	4ML - 6BL
FS.1 88	1	100 110	25 60	45 50	195 205	900	4ML
FS.1 90	1	120 130	25 60	45 55	205 215	1100	6BL
FS.1 92	1	130 150	25 60	50 60	215 225	1300	8E

FS.1 94	1	150 180	25 60	55 70	185 195	1500	9E
FS.1 95	1	150 250	25 60	60 70	205 215	1700	RIN 9E
FS.1 96	1	180 350	25 70	60 75	205 215	1900	RIN 10E
FS.1 98	1	240 350	80 90	80	205 215	2100	RIN L10E PLUS
FS.1 99	1	280 500	25 70	80		2500	RIN L10E PLUS
FS1 100	1	300 600	25 80	90 100	300	2800	RIN L13

Double share

TYPE	N. OF BODIES	POWER (HP)	WORKING WIDTH (CM)	WORKING DEPTH (CM)	HEIGHT (CM)	WEIGHT (KG)	MOULDBOARD
FSV.2 102	2 2+	240 280	100 140	35 45		2400	4MA
FSV.2 104	2 2+	250 300	100 140	35 50	205 215	2550	4ML
FSV.2 106	2 2+	280 350	100 140	65 80	205 215	2700	6BL
FSV.2 108	2 2+	330 450	60 140	65 80	205 215	3000	RIN 10E

F07 reversible movement with 2 hydraulic cylinders with memory - included

Алматы (7273)495-231	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Тверь (4822)63-31-35
Ангарск (3955)60-70-56	Ижевск (3412)26-03-58	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тольятти (8482)63-91-07
Архангельск (8182)63-90-72	Иркутск (395)279-98-46	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Астрахань (8512)99-46-04	Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)33-79-87
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Саранск (8342)22-96-24	Тюмень (3452)66-21-18
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Санкт-Петербург (812)309-46-40	Ульяновск (8422)24-23-59
Благовещенск (4162)22-76-07	Кемерово (3842)65-04-62	Ноябрьск (3496)41-32-12	Саратов (845)249-38-78	Улан-Удэ (3012)59-97-51
Брянск (4832)59-03-52	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Владивосток (423)249-28-31	Коломна (4966)23-41-49	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Владикавказ (8672)28-90-48	Кострома (4942)77-07-48	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Чебоксары (8352)28-53-07
Владимир (4922)49-43-18	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Челябинск (351)202-03-61
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Череповец (8202)49-02-64
Вологда (8172)26-41-59	Курск (4712)77-13-04	Петрозаводск (8142)55-98-37	Сургут (3462)77-98-35	Чита (3022)38-34-83
Воронеж (473)204-51-73	Курган (3522)50-90-47	Псков (8112)59-10-37	Сыктывкар (8212)25-95-17	Якутск (4112)23-90-97
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81		Тамбов (4752)50-40-97	Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

www.ermo.nt-rt.ru | | eor@nt-rt.ru